

HOIST PUSHBUTTON SWITCHES

THS-61 - Indirect Switching

Tend Pushbutton Hoist Switch - 240V 5A
Up/Down, Hoisting

THS-62 - Indirect Switching

Tend Pushbutton Hoist Switch - 240V 5A
Up/Down/East/West, Hoisting, Traverse or Longitudinal

THS-63 - Indirect Switching

Tend Pushbutton Hoist Switch - 240V 5A
Up/Down/East/West/North/South Hoisting, Traverse and Longitudinal



THS-82A - Direct Switching

Tend Waterproof Pushbutton Hoist Switch
Up/Down, Hoisting 240V 5A

THS-822A - Direct Switching

Tend Waterproof Pushbutton Hoist Switch
Up/Down/East/West, Hoisting, Traverse or Longitudinal

THS-8222A - Direct Switching

Tend Waterproof Pushbutton Hoist Switch
Up/Down/East/West/North/South
Hoisting, Traverse and Longitudinal

THS-8EI222A - Direct Switching

Same as THS-8222A with additional Emergency Stop Button
and Green illuminated



THS-83A - Indirect Switching

Tend Waterproof Pushbutton Hoist Switch - 240V 5A
Two Speed Up/Down, Hoisting.
Arrow indications on buttons

THS-836A - Indirect Switching

Tend Waterproof Pushbutton Hoist Switch - 240V 5A
Two Speed Up/Down, Single Speed East/West, Hoisting,
Traverse or Longitudinal. Arrow indications on buttons

THS-8366A - Indirect Switching

Tend Waterproof Pushbutton Hoist Switch - 240V 5A
Two Speed Up/Down, Single Speed East/West/North/South
Hoisting, Traverse and Longitudinal.
Arrow indications on buttons

THS-8EI366A - Indirect Switching

Same as THS-8366A with additional Emergency Stop Button
and illuminated Pushbutton Reset.
Arrow indications on buttons.



THS-EP213A - Direct Switching

Tend Pushbutton Hoist Switch
Up/Down with Emergency Stop Button & Red Indicator Light.
Arrow indications on buttons 240V 10A

THS-EP213E - Direct Switching

Hoist Switch as above with letter indication on buttons

THS-EP2132A - Direct Switching

Tend Pushbutton Hoist Switch
Up/Down/East/West, Emergency Stop Button & Red Indicator
Arrow indications on buttons. 240V 10A

THS-EI23E - Direct Switching

Tend Pushbutton Hoist Switch
Up/Down/East/West, with Emergency Stop & Green illuminated
Reset Button. Letter indication on buttons. 240V 10A.

